


Approach for investigations of progressive fatigue damage in 3D in fibre composites using X-ray tomography

Lars P. Mikkelsen and Kristine M. Jespersen

Composite and Material Mechanics


Department of Wind Energy

Technical University of Denmark




Fatigue damage evolution in fibre composites for wind turbine blades

- Why is fatigue a problem for wind turbine blades?
 - High number of load cycles throughout lifetime ($\sim 10^9$)
 - Fatigue is one of the main limiting factors of designing longer blades
- UD NCF glass fibre composite used for wind turbine blades in parts carrying main bending load
- Fatigue in UD NCF composites is a mechanism not well understood



Fatigue damage progression for NCF UD


Fatigue damage hypothesis




Ref: Jens Zangenberg, Povl Brønsted, and John W Gillespie Jr, 2013. *Fatigue damage propagation in unidirectional glass fibre reinforced composites made of a non-crimp fabric*, Journal of composite materials.

Experimental Fatigue Damage Assessment

Idea behind the method






Fatigue damage evolution



Non-crimp uni-directional composites for wind turbine blades

0: UD-side of non-crimp fabric


b_{45} : $\pm 45, 90$
backing layer




X-ray CT Experiments

Fitting large sample in CT scanner



- Special sample holder and short mount was made in order to fit the **410mm long** sample in the scanner
- Using this sample holder, it is possible to mount the sample in the same way at every interruption point with only a small variation.




Ex-situ X-ray CT results





A: 7300 cycles



Segment out the fiber failure



Segment out the fiber failure




**Gives good knowledge on the progression mechanism, but can we see all the damage features?
Cracks might be closed.**

Applying tension to the sample during scan


Applying load (outside scanner)

- Sample loaded in tensile test machine outside scanner and clamp is attached
- The clamp utilizes the curved specimen geometry for load transfer
- Carbon pins are tightened by screw while sample is loaded
- Load on the sample is released and the carbon pins keep the gauge region in tension.
- Using this solution it was possible to keep the sample at 0.17% strain (around 3-4kN) during scanning




Applying tension to the sample during scan

Results, zoom views




a) Zoom views for unloaded sample



Additional fibre fractures appear and off-axis cracks become more visible when applying tension during scanning. Applying a higher load is likely to have a more pronounced effect

Micro-mechanical modeling (Multiscale)



PhD summerschool and E-learning: CinemaxII

Multi-scale modelling: Understand stiffness drop and cure dependency of fatigue

Conclusions

- Location for fatigue damage was identified near backing bundles and typical at location with intertwining bundles
- Postulated fatigue damage evolution starting as transverse cracking in the backing bundles and subsequently spreading into the load carrying uni-directional fibers
- Fatigue damage evaluation was observed during non-destructive ex-situ X-ray CT scans
- Since the damage is observed in 3D, manual quantification is cumbersome and therefore work is ongoing on automatic UD fibre fracture quantification by image analysis.